

Recommended installation of t-nuts for Wilder Side mounts onto t-tracks

1. Orient the t-nut with the thread protrusions **facing down** into the track.



2 You may find it helpful to tip the t-nut into the track at the approximate location. This avoids dragging the t-nut across the bolt-heads that secure the track to the kayak, as seen in picture below. The other option is feed tracknut into end of track.



Installation helps: You may want to temporarily Support track nut underneath with a layer of foam or Cardboard to help with initial thread engagement.

3. Place a drop of red or blue loc-tite thread locker into the thread opening before final assembly.



4. Your design may come with double washers placed under the head of the bolt. Use one or both washers as needed to both secure the bolt to the t-nut but avoid bottoming out the bolt on the bottom of the t-track.